



# FIBRANT

## Caprolactam flakes

<b>Formula</b>	C <sub>6</sub> H <sub>11</sub> NO Molecular weight: 113.16 CAS No.: 105-60-2	
<b>Introduction</b>	<p>ε-Caprolactam is a monomer used in the manufacturing of Polyamide-6</p> <p>ε-Caprolactam typical use cases:</p> <ul style="list-style-type: none"><li>• Clothing, ropes, fishing nets;</li><li>• Packaging films;</li><li>• Engineering Plastics: Plates, rods, molded parts</li></ul> <p>Besides the above, Polyamide 6 is used in many other application fields.</p>	
<b>Appearance</b>	ε-Caprolactam flakes are a white, hygroscopic crystalline substance with a faint characteristic odor. -	
<b>Storage</b>	Store in a segregated, dry, cool and well-ventilated area. Caprolactam must be kept away from flammables, oxidizing agents, strong acids and bases and protected from moisture and direct sunlight.	
<b>Packaging</b>	Polyethylene bags. Net weights of bags 25 kg. ~ 1000 kg / pallet. Delivered in Full Container Loads.	
<b>Safety &amp; Application Info</b>	Always refer to the Material Safety Data Sheet (MSDS) for detailed information on safety, handling and disposal.	
<b>Physical properties</b>	Density	600-700 kg/m <sup>3</sup>
	Solidification/Melting point	69 °C
	Boiling point at 1013 mbar	270 °C
	Vapor pressure at 70 °C	±0.5 mbar
	Flash point (closed cup)	139 °C
	Auto-ignition temperature	395 °C



# FIBRANT

Specification	Parameter	Value	Analysis Method
	Water	max 0.050 % m/m	Intertek 1797. Karl-Fischer titration based on ISO 760
	Volatile bases	max 0.50 mmol/kg	Intertek 686. Distillation method based on ISO 8661
	Absorbance at 290 nm	max 0.050	Intertek 621. Spectrophotometric method based on ISO 7059
	Permanganate Absorption Number (PAN)	max 4.0	Intertek 1892. Spectrophotometric method based on ISO 8660
	Color	max 5 APHA	Intertek 1373. Spectrophotometric based on ISO 8112
	Alkalinity	max 0.050 mmol/kg	Intertek 1890. Potentiometric titration
	Acidity	max 0.050 mmol/kg	Intertek 1890. Potentiometric titration
	Ash <sup>1</sup>	max 10 mg/kg	Intertek 1971. Gravimetric method
	Insolubles in water <sup>1</sup>	max 5 mg/kg	Intertek 1972. Gravimetric method
	Iron <sup>1</sup>	max 0.5 mg/kg	Intertek 1397. Spectrophotometric method

<sup>1</sup> Skip lot testing

Sales	Fibrant BV
	PO Box 6, 6160 AA Geleen The Netherlands T +31(0)46 7022071 E <a href="mailto:ask.us@fibrant52.com">ask.us@fibrant52.com</a> <a href="http://www.fibrant52.com">www.fibrant52.com</a>

**Disclaimer:**

All data and information supplied by or on behalf of Fibrant B.V. (hereinafter Fibrant) with respect to its products are based on research and deemed to be reliable. However, since Fibrant has no influence on the use of the information and products after delivery to the buyer, Fibrant cannot accept any responsibility whatsoever in this respect. The buyer shall check the quality and all other properties of the product and assumes all responsibilities arising from the use of the products and the information related thereto and shall hold Fibrant harmless from and against any third party claims in respect thereof. Fibrant accepts no liability whatsoever ensuing from any infringement of rights to trademarks, patents, etc. owned or controlled by third parties that is the result of manufacturing application or sale of products by the buyer.

Revision date: 05-04-2020